


BHP 1000



BHP 1000

Model	Ref.	Art. Leader	Descrizione	Description
BHP 4"/8 INOX-INOX - LP608001	1	S3600423	Gruppo motore	Motor
BHP 4"/8 INOX-INOX - LP608001	2	P1200006	Guarnizione O.Ring	Joint O.Ring
BHP 4"/8 INOX-INOX - LP608001	3	P1220003	Gruppo tenuta meccanica AISI 302/304	Mechanical seal AISI 302/304
BHP 4"/8 INOX-INOX - LP608001	4	P1120027	Rosetta	Washer
BHP 4"/8 INOX-INOX - LP608001	5	P1120022	Anello seeger	Ring seeger
BHP 4"/8 INOX-INOX - LP608001	6	S3501096	Flangia camera olio	Flange
BHP 4"/8 INOX-INOX - LP608001	7	P1200139	Guarnizione O.Ring	Joint O.Ring
BHP 4"/8 INOX-INOX - LP608001	8	P1510052	Tappo M10	Cap M10
BHP 4"/8 INOX-INOX - LP608001	9	S3600424	Coperchio motore	Motor holder
BHP 4"/8 INOX-INOX - LP608001	10	P1200128	Guarnizione O.Ring	Joint O.Ring
BHP 4"/8 INOX-INOX - LP608001	11	S3600496	Portacondensatore + Cricchetto serracavo	Capacitor holder + Cable fastener
BHP 4"/8 INOX-INOX - LP608001	12	P1200138	Guarnizione O.Ring	Joint O.Ring
BHP 4"/8 INOX-INOX - LP608001	13	P1360050	Condensatore	Capacitor
BHP 4"/8 INOX-INOX - LP608001	14	S3600422	Cavo di alimentazione completo 15m H07RN-F Schuko	Cable 15M H07RN-F Schuko
BHP 4"/8 INOX-INOX - LP608001	15	P1100034	Vite	Screw
BHP 4"/8 INOX-INOX - LP608001	16	P1200062	Guarnizione O.Ring	Joint O.Ring
BHP 4"/8 INOX-INOX - LP608001	17	P1600043	Camicia esterna inox	Inox jacket
BHP 4"/8 INOX-INOX - LP608001	18	P1200026	Guarnizione O.Ring	Joint O.Ring
BHP 4"/8 INOX-INOX - LP608001	19	S3501104	Otturatore	Obturator
BHP 4"/8 INOX-INOX - LP608001	20	S3501105	Coperchio pompa	Pump cover
BHP 4"/8 INOX-INOX - LP608001	21	P1100012	Vite	Screw
BHP 4"/8 INOX-INOX - LP608001	22	P1220016	Gruppo tenuta meccanica AISI 316	Mechanical seal AISI 316
BHP 4"/8 INOX-INOX - LP608001	24	60112538	Albero esagonale	Hexagonal shaft
BHP 4"/8 INOX-INOX - LP608001	25	P1510057	Anello di rasamento	Clearance ring
BHP 4"/8 INOX-INOX - LP608001	26	S3501235	Tappo diffusore	Diffuser cap
BHP 4"/8 INOX-INOX - LP608001	27	S3501234	Diffusore	Diffuser
BHP 4"/8 INOX-INOX - LP608001	29	S3050007	Girante	Impeller
BHP 4"/8 INOX-INOX - LP608001	30	P1120014	Rosetta	Washer
BHP 4"/8 INOX-INOX - LP608001	31	P1120064	Rosetta grower	Washer
BHP 4"/8 INOX-INOX - LP608001	32	P1110009	Dado	Nut
BHP 4"/8 INOX-INOX - LP608001	33	P1230037	Boccola guida albero	Shaft pilot bush
BHP 4"/8 INOX-INOX - LP608001	34	S3501103	Ghiera diffusori 4"	Diffuser ring nut
BHP 4"/8 INOX-INOX - LP608001	35	S3501106	Base filtro	Filter base
BHP 4"/8 INOX-INOX - LP608001	36	G4550006	Nipplo 1" M/M con OR	Nipple 1" M/M with ORing
BHP 4"/8 INOX-INOX - LP608001	37	P1100006	Vite	Screw
BHP 4"/8 INOX-INOX - LP608001	38	P1120003	Rosetta elastica	Spring-washer
BHP 4"/8 INOX-INOX - LP608001	39	P1100017	Vite	Screw
BHP 4"/7 INOX-COMPOSITE - LP607002	40	P1120003	Rosetta elastica	Spring-washer
BHP 4"/7 INOX-COMPOSITE - LP607002	41	P1100017	Vite	Screw