

GENERADOR SPS1200

REF. N	CODIGO SPS1200	DESCRIPCION	CANTIDAD
1	GB5780-M5X10	Tornillo M5x10	2
2	GB93-5	Arandela muelle D5	2
3	GB95-5	Arandela D5	2
4	G1200-025	Tapa trasera alternador	1
5	GB5780-M6X90	Tornillo M6x90	4
6	GB93-6	Arandela muelle D6	4
7	GB95-6	Arandela D6	4
8	G1200-022	Soporte trasero alternador	1
9	G1200-020	Stator	1
10	GR1000A-10	Tornillo fijación rotor	1
11	G1200-017	Rotor	1
12	GB/T5789-M6X16	Tornillo M6x16	4
13	GR1000C05.01-00	Conjunto deposito combustible	1
14	GR1000C02.02-00	Carenado lado escape	1
15	GR1000C05.02-00	Conjunto tapón depósito combustible	1
16	GR1000C05-04	Base tapón	1
17	GR1000C02-03	Tapa inspección bujía	1
18	GB/T5789-M5X12	Tornillo M5x12	1
19	GB/T95-6	Arandela D6	15
20	GB/T818-M6X12	Tornillo M6x12	15
21	GR1000C03-02	Protector silenciador lado externo	1
22	GB/T845	Embellecedores	5
23	A152F	Motor	1
24	GR1000C03-03	Tapa superior	1
25	GR1000C03-04	Tapa inferios	1
26	GR1000C01.01-03	Conjunto filtro de aire	1
27	GB/T6184-M8	Tuerca M8	2
28	GR1000A-17	Soporte motor	1
29	GB/T95-8	Arandela D8	2
30	GB5781-M8X16	Tornillo M8x16	2
31	E80-015	Alerta aceite	1
32	GR1000C01.02-03	Conjunto silenciador	1
33	GR1000C03-01	Protector silenciador lado interno	1
34	SPS1200-34	Tuberia combustible	1
35	GR1000C05-03	Grifo combustible	1
36	GB/T93-6	Arandela muelle D6	1
37	GB/T6184-M6	Tuerca M6	1
38	SPS1200-38	Tuberia combustible	1
39	GR1000C02-01	Arandela	1
40	GB/T5789-M6X12	Tornillo M6x12	6
41	GR1000C02.03-03	Base generador	1
42	GR1000A-16	Antivibrante	4
43	GB/T96-6	Arandela D6	4
44	GB/T5781-M6X16	Tornillo M6x16	4
45	GB/T5781-M8X16	Tornillo M8x16	2
46	GB/T95-8	Arandela D8	2
47	GB/T5781-M8X25	Tornillo M8x25	2
48	GB/T5789-M4X10	Tornillo M4x10	2
49	GR1000C04-01	Soporte condensador	1
50	AC12MF250V	Condensador 12 MF	1

GENERADOR SPS1200

REF. N	CODIGO	DESCRIPCION	CANTIDAD
	SPS1200		
51	GR1000C02.01-03	Carenado lado cuadro	1
52	GB/T6178-M6	Tuerca M6	2
53	GR1000C02-02	Tapa inspección aceite	1
54	G1200B-033	Interruptor paro motor	1
55	G1200-027	Toma 230 V	1
56	SPS1200-56	Lámpara	1
57	SPS1200-57	Lámpara aceite	1
58	SPS1200-58	Protector	2
59	GR1000C04.01-01	Panel	1
60	GB/T5789-M6X12	Tornillo M6x12	4
61	G1200-033	Toma 12V	1
62	GR1000C04.01-02	Caja panel	1
63	SPS1200-63	Soporte anterior alternador	1
64	GB972-8	Arandela D8	4
65	GB5780-M8X20	Tornillo M8x20	4
66	GB972-8	Arandela D8	2
67	GB93-8	Arandela muelle D8	2
68	GB/T6178-M8	Tuerca M8	2
69	GB96-5	Arandela D5	1
70	GB/T919-M5X10	Tornillo M5x10	1

SPS-1200

