


BVP 1000



BVP 1000

Model	Ref.	Art. Leader	Descrizione	Description
BVP - LP530001	1	S3600326	Coperchio	Cap
BVP - LP530001	2	G4304016	Gruppo motore H80 inox	Motor H80 inox
BVP - LP530001	3	S3500106	Disco isolante	Insulation disk
BVP - LP530001	4	P1120051	Rosetta	Washer
BVP - LP530001	5	P1120003	Rosetta elastica	Spring-washer
BVP - LP530001	6	P1100003	Vite terra	Earth screw
BVP - LP530001	7	P1200007	Guarnizione O.Ring	Joint O. Ring
BVP - LP530001	8	P1100033	Vite	Screw
BVP - LP530001	9	S3500858	Corpo motore	Motor body
BVP - LP530001	10	P1100024	Vite	Screw
BVP - LP530001	11	P1120014	Rosetta	Washer
BVP - LP530001	12	S3500857	Girante	Impeller
BVP - LP530001	13	P1110009	Dado	Nut
BVP - LP530001	14	P1210008	Anello V.Ring	V.Ring
BVP - LP530001	15	S3500963	Anello motore	Motor Ring
BVP - LP530001	16	P1200025	Guarnizione O.Ring	Joint O. Ring
BVP - LP530001	17	S3500860	Piedistallo	Pedestal
BVP - LP530001	18	S3500861	Fondello	Base
BVP - LP530001	19	P1100097	Vite	Screw
BVP - LP530001	20	P1200118	Guarnizione O.Ring	Joint O. Ring
BVP - LP530001	21	S3600369	Gomito 1.1/2" M x 1.1/2"F	Elbow
BVP - LP530001	22	S3500336	Anello antistrappo	Anti-tear ring
BVP - LP530001	23	S3500335	Clip pressacavo	Cable fastener
BVP - LP530001	24	P1100008	Vite	Screw
BVP - LP530001	25	P1360003	Condensatore	Capacitor
BVP - LP530001	26	P1230003	Passacavo d9	Grommet d9
BVP - LP530001	27	P1380037	Galleggiante	Floatswitch
BVP - LP530001	28	P1330004	Cavo di alimentazione 10m. H07RN-F	Cable 10m. H07RN-F
BVP - LP530001	29	S3600370	Raccordo portagomma 1.1/2"-D.50-1.1/4" D.40	Pipe fittings 1.1/2"-D.50-1.1/4" D.40
BVP - LP530001	30	P1120073	Rosetta elastica	Spring-washer