




SPARE PARTS LIST DA18:

POS.	CODE	ARTICLE	Q.TY
1	S00254050	HANDLE DS1/2	1
2	C00164410	WASHER D6	1
3	S00192100	SCREW M6X16	1
4	S00165400	FAIRLEAD M30	1
5	S00112290	FAIRLEAD	1
6	C00191850	SCREW M5X14	1
7	S00092242	PLATE AG10/20 M20	1
8	S00092282	PLATE DA18/26 WIT FLOAT	1
9	S00131980	GASKET	1
10	S00092120	TANK BODY	1
11	S00132500	OR GASKET D.117,1X3,53	1
12		ITEM NOT ASSEMBLED/SUPPLIED	1
13	S00022380	STATOR S.F. 125X65X90 220/50 DA18	1
14	S00022382	STATOR S.F. 125X65X90 220/60	1
15	S00022388	STATOR S.F. 125X65X90 240/50	1
16		ITEM NOT ASSEMBLED/SUPPLIED	1
17		ITEM NOT ASSEMBLED/SUPPLIED	1
18	S00022386	STATOR T.F. 125X65X90	1
19	S00022389	STATOR T.F. 125X65X90 415/50	1
20		ITEM NOT ASSEMBLED/SUPPLIED	1
21	C00192740	SCREW M5X8	1
22	S00031370	INOX TUBE DA18/26	1
23	S00002248	OVERLOAD 100C 25A	1
24	P00081030	BEARING 6203 ZZ	1
25	S00012240	SHAFT WITH ROTOR DA18	1
26	C00152200	KEY 5X5X15	1
27	S00081044	BEARING 6204	1
28	S00121380	MECHANICAL SEAL D.18	1
29	S00121390	COUNTER FACE 33X10	1
30		ITEM NOT ASSEMBLED/SUPPLIED	1
31	S00051090	PUMP BODY DA18/26	1
32	S00141660	SPACER DA20/30	1
33	S00151640	WASHER D13	1
34	C00201270	NUT M12	1
35		ITEM NOT ASSEMBLED/SUPPLIED	1
36	S00211370	BASE DA18/26	1
37	A00193130	SCREW M8X14	1
38	S00061840	IMPELLER DA18	1
39	S00061841	IMPELLER DA18/60Hz	1
40		ITEM NOT ASSEMBLED/SUPPLIED	1
41		ITEM NOT ASSEMBLED/SUPPLIED	1
42		ITEM NOT ASSEMBLED/SUPPLIED	1
43		ITEM NOT ASSEMBLED/SUPPLIED	1
44		ITEM NOT ASSEMBLED/SUPPLIED	1
45	P00112070	FAIRLEAD	1
46	P00165600	FLOAT DA18	1
47	S00260172	FAIRLEAD PG9	1
48	S00032164	SCHUKO PLUG 35 MF	1
49	S00091150	CONDENSER 35 MF 400V	1
50	C00091100	CONDENSER 40 MF 400V	1
51	S00111440	CABLE 4G1,5 MMQ NEOPRENE MT 10	1
52	C00111452	CABLE 4G1,5 MMQ PVC MT 10	1